




D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage  
 PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу  
 RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage  
 SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató





1/5



Name-Naam-Nazwa-Isim-Название-Nom-Nome-Jméno-Názov-Név-Denumire

# ERGO DNO 90x200


US 4x16 			WP M6x25 	UP 5x20 	f-30 h-4 
A7 x 12	A8 x 2	A9 x 2	A10 x 8	A11 x 18	A12 x 18




A15 x 18



A13




A14 x 2




Service-Dienstverlening-Serwis-Service-Сервисная Служба-Assistenza-Szerviz

A7	A14
A8	A15
A9	A16
A10	
A11	
A12	
A13	








**ANADIA**



**A16**




**a**




**a**

**A9+A7**






**C**




STELAŽ ERGO SPACE






8

5/5



9



10

